



DRAWING PROVIDED SO FITMENT CAN BE CHECKED FOR YOUR APPLICATION. CHAINSTAY CLEARANCE REQUIREMENTS VARY BETWEEN MANUFACTURER AND EVEN BETWEEN MODELS, WE CANNOT TEST FIT THESE CRANKS ON EVERY MODEL OF BIKE SO PLEASE CHECK YOUR NEEDS AGAINST THIS DRAWING.

Q-FACTOR (A) AND OFFSET FROM CENTRELINE (B) WILL VARY DEPENDING ON MODEL OF MOTOR, DIMENSIONS ARE SHOWN FOR BOSCH AND BROSE SYSTEMS